

NOTE: You can **not** send SMS to mobile phones!

Send a message from an e-mail account:

To: 881612345678@msg.iridium.com

Limit 160 characters.

Send a message from the Iridium homepage:

<http://messaging.iridium.com/>

Limit 160 characters.

SMS between Iridium subscribers:

Select the menu option: "Message Editor"

Enter your message (User's Guide page 104→)

Select "OK"

Select the menu option: "Send Message"

Enter <Iridium phone number>

Select "Send Message"

Replying to a SMS:

Select "Received Messages"

Select your message

Select "Reply to Sender"

Enter the text

Select "Send Message"

You will be asked to enter the destination number with the originator's phone number pre-populated as the destination number. If this is not the desired number, then enter the correct one.

Send SMS message from 9505A phone to e-mail:

Press the Envelope key on the handset.

Use the Scroll Key to select the "Message Editor".

Press "OK"

Enter the destination e-mail address, e.g.

info@polaris-as.dk (@ press "1" seven times)

Enter a blank space by pressing the # twice or down arrow on the Scroll Key twice.

Enter message, press "OK"

Select "Send Message" by pressing "OK"

Destination number: **+*2** or **00*2**, then press "OK"

*** = asterix left to the 0 button.**

Displaying "Sending Message" and then "Message sent" if successfully delivered.

Replying to an e-mail message:

Select "Received Messages"

Find the message.

Select "Reply to sender" write your message.

Select "Send Message" and **+*2** will automatically be added. Select Send Message.



HELPFUL HINTS

- Need clear view of sky, outdoors, away from buildings and tall structures. Rotate and fully extend antenna into a vertical position.
- Wait until registration is complete (you will see  Registered and the  and  indicators). If no registration ( missing), press  .
- To dial, press: [ ] or [ ] and hold for two seconds, [country code], [phone number], .
- Talk with antenna above your head and vertical to the ground.

Short user manual

Iridium Satellite Phone

Handheld
Motorola 9505/9505A



Polaris Electronics A/S

Kaerholt 1

DK-9210 Aalborg SO

Phone: +45 9631 7900

Fax: +45 9631 7901

E-mail: info@polaris-as.dk

Home-page: www.polaris-as.dk

Making a phone call from Iridium to cellular or mobile phone.

Always remember the country code, as Iridium is to be seen as a country.

This means that even though you are in Denmark you will have to use the country code +45.

Making a phone call to Iridium from cellular or mobile phone.

Use the voicenummer +8816 xxx xxxxx.

Test the satellite phone - free of charge:

By dialling +1-480-752-5105 from the satellite phone, you can verify that the phone is working properly and familiarize yourself with the phone's operation - all free of charge. You will hear a recorded message confirming that the call was completed and offering quick tips on proper handset usage. This automated service allows you to test the phone whenever and wherever you like.

Unblock the PIN.

If your PIN code is entered incorrectly three times in a row, BLOCKED appears in the display. You need to enter a PIN unblocking key (PUK1).

Press *, *, 0, 5, *

Enter the eight digit unblocking key (PUK1), and press "OK"

Enter a new PIN code and press "OK"

Re-enter the new PIN code, and then press "OK"

To set-up Iridium voicemail, please follow the instructions below.

Ensure that your Iridium telephone has an active SIM card installed and that the unit is switched on and registered with the satellite.

Dial 0088 1662 990000 and press OK on your Iridium handset. After a short pause you will hear the message *"You have now accessed the Iridium messaging centre, please enter the number of the person you are trying to reach."*

Dial your own Iridium telephone number in the following format 8816 XXXX XXXX. You will hear the message *"You have reached the voicemail of 8816 XXXX XXXX."*

Before the message ends press * (asterix) located on the bottom left hand of the keypad. You will hear the message *"Please enter your password"*, which is the last seven digits of the Iridium telephone number set as default password. Typically this will be 1XXXXXX.

DO NOT PRESS "OK" AFTER ENTERING YOUR PASSWORD

You have now accessed your Iridium messaging service. By following the voice prompts, you can personalise your outgoing message, change your access password and customise many other advanced features. To ensure full operation of your Iridium handset you should: record an outgoing message, change your access password to an easy to remember 4 digit code and record your name in the message preferences when prompted. Now your Iridium telephone is ready to receive messages.

NB "Pound" is an American expression to what we know as the "#" key.

Voice mail services on Iridium telephones can be switched on or off by the user.

(Please note that the default setting for currently available iridium equipment is "forward when unavailable")

This setting is accessed by selecting "call related features" from the menu. Use cursor key scroll up or down to "call forwarding". Select view options, if telephone is registered with the system and with good signal strength, the status "call forwarding" is displayed. It is then simply a case of switching it on or off according to user preference and wait for 30 seconds approx for the system to update your choice. The choice of call forwarding should be "forward when unavailable" "voicemail".

Service center

You might be asked to register this service number in the phone: **008816 6290 0005**

Troubleshooting.

- Try the manual.
- Call Polaris Electronics A/S.
- Call 2222 a call free number. Do **not** use country code 00, because then the number is NOT for free.